




1. BOLT, SPRING, COVER




2. LEAD WIRE, PLUG, CAP




3. LABEL, FUEL HOSE




4. TOOL SET




5. GASKET SET




6. FRAME & TANK




7. GRNERATOR




8. CONTROL BOX




(A) CYLINDER BLOCK GROUP




(B) CYLINDER HEAD GROUP




(C) HEAD COVER GROUP




(D) CASE COVER GROUP




(E) CRANKSHAFT GROUP




(F) PISTON & ROD GROUP




(G) MAGNETO GROUP




(H) AIR CLEANER GROUP




(I) CARBURETOR GROUP




(J) CONTROL PANEL GROUP




(K) FAN COVER GROUP



(N) COCK GROUP



(R) RECOIL STARTER GROUP



(W) OIL SENSOR GROUP

